


Cox Hall Tech System How-To Guide



Cox Hall- Siskiyou and Cox Classroom System

Using a Personal Laptop Computer:

1. Find the touch screen on the left side of the podium



2. Push "Show Laptop"
 - a. This should turn on the projector automatically
3. Plug in the laptop using the HDMI cord




4. The projector should automatically project what is on the laptop



5. To play sound, you will need to plug in the audio cord
6. There is a small gray wheel sound control on the top of the podium on the right side.

Streaming Movies From SOU Service

1. Find the touch screen on the left side of the podium




2. Push "Show Laptop"
 - a. This should turn on the projector automatically
3. Plug in the laptop using the HDMI cord



4. The projector should automatically project what is on the laptop
5. To play sound, you will need to plug in the audio cord
6. There is a small gray wheel sound control on the top of the podium on the right side.
7. Make sure you are signed into the SOU Guest wifi.
8. Go to Movies.sou.edu and select a movie to watch.

Playing DVD:

1. Find the touch screen on the left side of the podium




2. Push "Play a DVD"
3. At the bottom control panel please select Open on the DVD player



4. Put in the DVD and push the play button.
5. The projector should automatically project what is on the laptop
6. There is a small gray wheel sound control on the top of the podium on the right side.

Turning Off System:

1. Find the touch screen on the left side of the podium



2. Push "Turn Off"
3. The system should turn off automatically.

Questions:
Please contact SOU Conference Services at
541-944-1408